

Congratulations on purchasing this product

PGWU-61B
PGWX-61B
PGXG-61B




Quick Setup Guide



1 Packaging Contents



AAA (2x)





2 Lens Assembly A



Remove protective covers from both ends of the lens before starting assembly.


3 Lens Assembly B





Pull the lever towards the front while sliding in the lens.

4 Rear Cover

Loosen 3 screws to remove rear cover and gain access to the inputs panel.



5 Ceiling Mount*




Unit Weight: 18 kg max.


Please check the manual of your supportsystem for compatability

*(Ceiling mount system is not included)


6 Input Cables



(See User Manual for detailed info on Inputs)



7 Remote Control



Quick Keys


(for Remote and keypad)

Quick Key 1

Push Menu-UP twice for instant 'Picture Mute'


Quick Key 2

Push Menu-OK for quick access to the Focus/Zoom Menu




8 Starting Projector

IR Position Front




IR Position Rear



Status Led



9 OSD Lite Menu



- INPUT Toggle between input sources
- BRIGHTNESS adjust lamp brightness level
- CONTRAST adjust image contrast
- COLOR adjust image colour
- ASPECT RATIO modify image aspect ratio
- LENS FOCUS adjust lens focus
- LENS ZOOM adjust lens zoom
- LENS SHIFT adjust lens shift
- KEystone adjust keystone
- LANGUAGE select language
- INFO information on lamp status
- MODE normal/eco/power
- SERVICE service information
- ADVANCED see user manual

10 Important Info



- Remove the lens before transporting the projector.
- To save lamp lifetime, first switch the projector to standby mode and wait two minutes, then switch off the main power.
- Ensure that the projector is operating with clean filters.
- Do not block the ventilation in -and outlets.
- Using the projector at a non recommended tilt angle will reduce the lifetime of the lamps or create unexpected behaviour of the unit.
- Laser light can cause severe damage to the DMD. This damage is not covered by warranty.



For more information and Maintenance Guidelines, check the Detailed User Manual on: <http://www.barco.com/en/products-solutions/projectors>