




1



2







01 SS USB 3.0

USB 3.0 ()

10 /

10




Type-C

Type-C

10 /




/ /



6 BIOS



USB 2.0



USB 3.0

USB 2.0 ()

480

USB 3.0 ()

10

/



RJ45
Ethernet,
(LAN)

2,5 / — 1,0 /



DisplayPort

DisplayPort
60 4K

⑪ HDMI

HDMI

HDMI (High Definition Multimedia) —

- /



MiniPC

MiniPC

Step1

HDMI DP




Step2

USB, Type-C.



Step3




Step4



Step1

BIOS.

Delete ESC,



Step2

BIOS

Ctrl+R

Ctrl R

)

(

)

Ctrl+G,

(

).

Ctrl+B,

Step3

F4,

20

MiniPC.

5 35