

Viewline / Premline Linear

Mounting Instruction

General safety information

- To reduce the risk of personal injury or property damage from fire, electric shock, falling parts, cuts/abrasions and other hazards. Please read all warnings and instructions included with and on the fixture box and all fixture labels.
- Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.
- Commercial installation, service and maintenance of luminaires should be performed by a qualified licensed electrician.
- For Residential installation: If you are unsure about the installation or maintenance of the luminaires, consult a qualified licensed electrician and check your local electrical code.

Do not install damaged products!

CAUTION: RISK OF INJURY

- Wear gloves and safety glasses at all times when removing luminaire from carton, installing, servicing or performing maintenance.
- Avoid direct eye exposure to the light source while it is on.
- Account for small parts and destroy packing material, as these may be hazardous to children.


CAUTION: RISK OF FIRE

- Keep combustible and other materials that can burn away from luminaire and lamp/lens.
- MIN 90°C supply conductors.

Operating characteristic:


Voltage input: 200/240V 50/60 Hz

Operating temp: -40°F to 104°F




sudopt®


Cord pendant mounting




①




②




③



④




⑤




⑥


Rod pendant mounting




①




②




③



④




⑤




⑥


Surface mounting




①



②




③




④


Recessed mounting




①



②




③




④


Continuous connection




①




②



③



④



⑤